



morphy richards

3 Year
Guarantee*

*Upon registering your product
at morphyrichards.co.uk

Cookware Care and Use

Please read and keep these instructions for future use.

- Before first use remove all paper and labels and wash your cookware in warm soapy water. Rinse and dry thoroughly.
- If the cookware has a non-stick coating, metal tools should not be used in order to protect the non-stick coating.
- Oven safe to 180°C / 360°F / Gas Mark 4; unless otherwise specified.
- Never allow your cookware to boil dry. When this happens, immediately turn off the heat and do not remove the pan from the stove top until it has cooled down.
- Thanks to the fast and efficient heat conductivity of the materials used, cooking on medium or lower temperature is sufficient and energy saving. High heat may damage or discolour your cookware and continually overheating may cause food to burn. The guarantee does not cover damage to the non-stick coating if this is caused by overheating.
- Place your pan in the centre of a cooking ring where the diameter is not larger than the diameter of the base of the cookware. For example, cookware with a diameter of 20cm can best be used on a cooking ring with a diameter smaller than 20cm.
- Remove burnt-on foods by soaking for a few minutes in hot soapy water. If scrubbing is necessary, use a nylon pad with warm, soapy water or a non-abrasive silicate-based cleanser.
- Always lift cookware from the hob. Never drag or slide it, as this can damage both the surface of the pan and the hob.



morphy richards

Cookware Care and Use

- Always make sure cookware is dried thoroughly before storage.
- Take care when storing your cookware – stacking may result in scratches on the non-stick coating.
- Oven gloves are recommended (handles can get hot); especially when cookware is placed in the oven.
- For safety reasons, cookware should never be left unattended when cooking
- Always let cookware cool off before submerging in water.
- This product is dishwasher safe but we recommend hand washing to prolong the performance of the non-stick coating.
- Do not use metal scourers or harsh abrasives to remove stubborn bits of food as these may damage the non-stick coating.
- Do not add salt to cold liquid in your pan – add when the liquid is hot.
- Do not pour cold liquid into a hot pan.



**To validate your 3 year guarantee,
scan the QR code or register online
at www.morphyrichards.co.uk**

Morphy Richards

9 Cabot Lane, Poole, Dorset, BH17 7BY, UK

