

## Health and Safety

The use of any electrical appliance requires the following common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

**WARNING: Danger to the person!**

**IMPORTANT: Damage to the appliance!**

In addition, we offer the following safety advice.

### Location

- This appliance is intended to be used in household and similar applications such as:
  - farm houses;
  - by clients in hotels, motels and other residential type environments;
  - bed and breakfast type environments.
- It is not suitable for use in staff kitchen areas in shops, offices and other working environments.
- Remove all the packaging and retain for future reference.
- Ensure the Accents One Cup machine is used on a firm, flat surface.
- Do not use the Accents One Cup machine outdoors or near water.
- Do not place the Accents One Cup on a highly polished wooden surface as damage may occur to the surface.
- Do not place the Accents One Cup on or near hot surfaces such as a hot plate, radiant rings or near a naked flame.
- **WARNING:** Do not place the Accents One Cup onto a metal tray or metal surface whilst in use.

### Mains cable

- Do not let the mains cable hang over the edge of the worktop where a child could reach it.
- Do not let the cable run across an open space e.g. between a low socket and table.
- Do not let the cable run across a cooker or other hot area which might damage the cable.
- The mains cable should reach from the socket to the base unit without straining the connections.
- If the supply cable is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

### Other safety considerations

- Keep the outside of the Accents One Cup area clean and dry at all times.
- Do not immerse the Accents One Cup itself in water and always ensure the electrical connections are kept dry.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Ring the helpline number for advice on examination and repair.
- The use of attachments or tools not recommended or sold by Morphy Richards may cause fire, electric shock or injury.
- Do not use the Accents One Cup for anything other than its intended purpose.
- Do not leave the appliance unattended whilst in use.
- This machine is only intended to boil hot water, do not put tea or coffee into the machine.

### Product safety

- Never use warm or hot water to fill the water chamber.
- Do not overfill the water chamber.
- **Personal safety**
- Do not touch metal parts until the unit has cooled.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not move the Accents One Cup when switched on.

### Children

- Children do not understand the dangers associated with operating electrical appliances. Never allow children to use this appliance.
- Children should be supervised to ensure that they do not play with the appliance.

### Treating scalds

- Run cold water over the affected area immediately. Do not stop to remove clothing, get medical help quickly.

### Electrical requirements

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C. (Alternating Current).

If the socket outlets in your home are not suitable for the plug supplied with this appliance the plug should be removed and the appropriate one fitted.

**WARNING:** The plug removed from the mains lead, if severed, must be destroyed as a plug with a bared flexible cord is hazardous if engaged into a live socket outlet.

Should the fuse in the 13 amp plug require changing, a 13 amp BS1362 fuse must be fitted.

**WARNING:** This appliance must be earthed.

KT43930 MUK Rev 3 06/11

## Registering your 2 year guarantee

Your standard one year guarantee is extended for an additional 12 months when you register the product within 28 days of purchase with Morphy Richards. If you do not register the product with Morphy Richards within 28 days, your product is guaranteed for 1 year. To validate your 2 year guarantee register with us online at [www.morphyrichards.co.uk](http://www.morphyrichards.co.uk)

Or call our customer registration line

UK 0844 871 0962

IRE 1800 409 119

N.B. Each qualifying product needs to be registered with Morphy Richards individually.

Please note that the 2 year guarantee is only available in the UK and Ireland. Please refer to the one year guarantee for more information.

## Your 1 year guarantee

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 12 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced as appropriate and dispatched usually within 7 working days of receipt.

If, for any reason, this item is replaced or repaired during the 1 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 1 year guarantee, the appliance must have been used according to the instructions supplied. For example, crumb trays should have been emptied regularly.

## Exclusions

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.
  - 2 The appliance has been used on a voltage supply other than that stamped on the products.
  - 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
  - 4 The appliance has been used for hire purposes or non domestic use.
  - 5 The appliance is second hand.
  - 6 Morphy Richards reserves the right not to carry out any type of servicing under the guarantee at its discretion
  - 7 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.
  - 8 Batteries and damage from leakage are not covered by the guarantee.
- This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer. Morphy Richards products are intended for household use only. See usage limitations within the location safety instructions.

## Disclaimer

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of its models at any time.



For electrical products sold within the European Community. At the end of the electrical products useful life, it should not be disposed of with household waste.

Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country

**IF YOU ARE HAVING A PROBLEM  
WITH ONE OF OUR PRODUCTS, CALL  
OUR HELPLINE:**

**UK: 0844 871 0960  
EIRE: 1800 409 119  
SPARES: 0844 873 0726**

**morphy richards**

The After Sales Division  
Morphy Richards Ltd  
Mexborough, South Yorkshire,  
England, S64 8AJ

Helplines (office hours)  
UK 0844 871 0960  
Spare Parts 0844 873 0726  
Republic of Ireland 1800 409 119  
[www.morphyrichards.com](http://www.morphyrichards.com)



KT43930 MUK Rev 3

# morphy richards®

## Accents one cup



For competitions, product hints and tips  
and more join us at



[www.homeofthehouseproud.com](http://www.homeofthehouseproud.com)



[www.facebook.com/loveyourhome](http://www.facebook.com/loveyourhome)




[www.twitter.com/loveyourmorphy](http://www.twitter.com/loveyourmorphy)

[www.morphyrichards.com](http://www.morphyrichards.com)

\* Register online for your 2 year guarantee. See back of this instruction book for details. (UK and Ireland customers only)


## Product overview




## Features

- (1) Water Chamber
- (2) Lid
- (3) On/Off Button  
(Illuminating)
- (4) Water Dispenser
- (5) Drip Tray Cover
- (6) Drip Tray


## Using your Accents One Cup




Assemble the Accents One Cup as above.




Fill a cup with cold water.



Pour the water into the Water Chamber (1).  
(min 150ml, max 300ml)



Close the Lid (2).



Place the empty cup below the Water  
Dispenser (4) on the Drip Tray (6).



Press and release the On/Off Button (3)  
and wait for the boiling water to be  
dispensed.

## Before first use

It is important to clean your Accents One Cup before first use or if it has not been used for a long period of time.

To clean, follow steps 1-6 above three times, discarding the water after each cycle.

## Cleaning your Accents One Cup

- 1 Disconnect the appliance from the mains supply.
- 2 Make sure the appliance has completely cooled down.
- 3 Simply wipe the exterior with a clean, damp cloth.  
Do not use any abrasives or metal scourers as this will damage the finish on the unit.
- 4 Remove the Drip Tray Cover and Drip Tray from the appliance and remove any spilt water then clean with a damp cloth or a damp sponge.

## Descaling

- 1 Disconnect the appliance from the mains supply.
- 2 Make sure the appliance has cooled down completely.
- 3 Fill the Water Chamber with a descaling solution (e.g. Oust.)
- 4 Leave to stand for 15 minutes.
- 5 Place an empty container under the Water Dispenser to gather the descaled hot boiled water.
- 6 Connect the appliance to the mains supply.
- 7 Press the On/Off Button, water will flow through the unit. Allow the unit to keep dispensing until the Water Chamber is empty.
- 8 Repeat the process with cold water three times in order to flush the system.

## Contact us

### Helpline

If you are having a problem with your appliance, please call our Helpline, as we are more likely to be able to help than the store you purchased the item from.

Please have the product name, model number and serial number to hand when you call to help us deal with your enquiry quicker.

UK Helpline: 0844 871 0960

IRE Helpline: 1800 409 119

Spares: 0844 871 0926

### Talk To Us

If you have any questions or comments, or want some great tips or recipe ideas to help you get the most out of your products, join us online:

Blog: [www.homeofthehouseproud.com](http://www.homeofthehouseproud.com)

Facebook: [www.facebook.com/loveyourhome](http://www.facebook.com/loveyourhome)

Twitter: [www.twitter.com/loveyourmorphy](http://www.twitter.com/loveyourmorphy)

Website: [www.morphyrichards.com](http://www.morphyrichards.com)

## Troubleshooting

Problem	Reason	Solution
<ul style="list-style-type: none"> <li>• The On/Off Button will not work</li> </ul>	<ul style="list-style-type: none"> <li>• Your Accents One Cup needs to reset after the last use</li> </ul>	<ul style="list-style-type: none"> <li>• Wait for 5 seconds and try again</li> </ul>
<ul style="list-style-type: none"> <li>• The temperature of the water seems cooler</li> </ul>	<ul style="list-style-type: none"> <li>• There may be a build up of limescale</li> </ul>	<ul style="list-style-type: none"> <li>• Descale your Accents One Cup, refer to the descaling section.</li> </ul>
<ul style="list-style-type: none"> <li>• Does not boil, there is no illumination</li> </ul>	<ul style="list-style-type: none"> <li>• Your Accents One Cup is not plugged in</li> <li>• There is no water in the chamber</li> </ul>	<ul style="list-style-type: none"> <li>• Plug in and switch on at the socket</li> <li>• Fill the chamber with the required volume of cold water</li> </ul>
<ul style="list-style-type: none"> <li>• Occasionally water drips from the spout after the unit has dispensed water</li> </ul>	<ul style="list-style-type: none"> <li>• There may be a small amount of residual water left in the unit after it has been dispensed</li> </ul>	<ul style="list-style-type: none"> <li>• This is normal, the drip tray will catch any drops that occur</li> </ul>
<ul style="list-style-type: none"> <li>• There is steam coming through the top of your Accents One Cup</li> </ul>	<ul style="list-style-type: none"> <li>• As with a standard kettle, boiling water will produce steam which needs to be released</li> </ul>	<ul style="list-style-type: none"> <li>• This is normal, your Accents One Cup has been designed to direct steam in this way</li> </ul>