

SIZE:148x210mm

Registering Your 2 Year Guarantee

Your standard one year guarantee is extended for an additional 12 months when you register the product within 28 days of purchase with Morphy Richards. If you do not register the product with Morphy Richards within 28 days, your product is guaranteed for 1 year. To validate your 2 year guarantee register with us online at www.morphyrichards.co.uk

Or call our customer registration line quoting model and serial number, these numbers can be found on the base of the product.

UK 0344 871 0242
IRE 1800 409 119

N.B. Each qualifying product needs to be registered with Morphy Richards individually.

Please note that the 2 year guarantee is only available in the UK and Ireland. Please refer to the one year guarantee for more information.

Your 1 Year Guarantee

It is important to retain the retailer's receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 12 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions), the faulty appliance will then be repaired or replaced as appropriate and dispatched usually within 7 working days of receipt.

If, for any reason, this item is replaced or repaired during the 1 year guarantee period, the guarantee on the new item will be calculated from original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 1 year guarantee, the appliance must have been used according to the instructions supplied. For example, crumb trays should have been emptied regularly.

IF YOU ARE HAVING A PROBLEM WITH ONE OF OUR PRODUCTS, CALL OUR HELPLINE:

UK: 0344 871 0944
EIRE: 1800 409 119
SPARES: 0344 873 0710

morphyrichards

Stoney Lane
Prescot
Merseyside
L35 2XW
UK

Helplines (office hours)
UK 0344 871 0944
Spare Parts 0344 873 0710
Republic of Ireland 1800 409 119
www.morphyrichards.com



Exclusions

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturer's recommendations or where the fault has been caused by power surges or damage caused in transit.
 - 2 The appliance has been used on a voltage supply other than that stamped on the products.
 - 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
 - 4 The appliance has been used for hire purposes or non domestic use.
 - 5 The appliance is second hand.
 - 6 Morphy Richards reserves the right not to carry out any type of servicing under the guarantee at its discretion
 - 7 Batteries and damage from leakage are not covered by the guarantee.
- This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer. Morphy Richards products are intended for household use only. See usage limitations within the location safety instructions.

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore

Disclaimer

reserves the right to change the specification of it's models at any time.



For electrical products sold within the European Community. At the end of the electrical products useful life, it should not be disposed of with household waste.


Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country

morphyrichards
smart ideas for your home

soupmaker



Please read and keep these instructions for future use



Download the Morphy Richards
Cook & Create app for recipe ideas



For competitions, product hints and tips
and more join us at



www.morphyrichards.co.uk/blog



www.facebook.com/morphyrichardsuk



@loveyourmorphy

www.morphyrichards.com

Raspberry Smoothie

Preparation time: 5 minutes

Mixing time: 2 minutes

Setting: Juice

Makes: 1.5L

Ingredients:

- 900ml low fat raspberry yoghurt
- 300ml semi skimmed milk
- 300g raspberries (allow to thaw if frozen)

Method:

- 1 Place ingredients into the Soup Maker, stir thoroughly.
- 2 Select the juice setting and simply wait for 2 minutes until the Soup Maker has finished.
- 3 Serve straight away.

Strawberry and Pineapple Smoothie

Preparation time: 5 minutes

Mixing time: 2 minutes

Setting: Juice

Makes: 1.1L

Ingredients:

- 300g fresh strawberries
- 250g fresh pineapple, peeled
- 450g low fat strawberry yoghurt
- 150ml semi skimmed milk
- 1 scoop of vanilla ice cream

Method:

- 1 Prepare and hull the strawberries, cut any large ones in half. Chop the pineapple into chunks.
- 2 Place ingredients into the Soup Maker, stir thoroughly.
- 3 Select the juice setting and simply wait for 2 minutes until the Soup Maker has finished.
- 4 Serve straight away.

Chocolate Banana Smoothie

Preparation time: 10 minutes

Mixing time: 2 minutes

Setting: Juice

Makes: 1.5L


Ingredients:

- 2x450g cartons low fat vanilla yoghurt
- 300-400ml semi skimmed milk (to taste)
- 2 bananas, peeled and sliced thinly
- 4tbsp caster sugar
- 100-150g dark chocolate (to taste)

Method:

- 1 Melt the chocolate in either a microwave or over a pan of hot water.
- 2 Add all ingredients to the Soup Maker, adding the melted chocolate last. Stir thoroughly.
- 3 Select the juice setting and simply wait for 2 minutes until the Soup Maker has finished.
- 4 Serve straight away.

Product Overview



Features

- | | |
|----------------------|--------------------------------|
| (1) Lid Handle | (10) LED Screen |
| (2) Lid | (11) Select On/Off Button |
| (3) Jug | (12) Smooth Function Indicator |
| (4) Jug Handle | (13) Chunky Function Indicator |
| (5) Power Socket | (14) Juice Function Indicator |
| (6) Over Fill Sensor | (15) Blend Function Indicator |
| (7) Motor Housing | |
| (8) Mixing Blade | |
| (9) Mode Button | |

Introduction

Thank you for your recent purchase of the Morphy Richards Soup Maker. Please read this instruction booklet carefully before you use your Soup Maker for the first time.

We've designed your Soup Maker so that it's quick and easy to make homemade soup to your own individual taste, with minimum fuss. All you have to do is place the ingredients needed for your favourite recipe inside your Soup Maker, then it's as simple as selecting either the smooth or chunky soup setting, depending on your preference. A short wait while your Soup Maker blends and gently cooks the ingredients for perfectly delicious homemade soup. It really couldn't get any simpler!

Remember to visit www.morphyrichards.co.uk to register your product's two year guarantee.

Contents

Health And Safety	2
Features	3
Introduction	4
Before First Use	5
How To Use Your Soup Maker	5
Using Your Soup Maker	6
LED Screen	6
The Benefits Of Homemade Soup	7
What Makes Your Soup Maker So Special?	7
Any Questions?	7
A Dream To Clean	8
Recipes	9
Recipes - Soup	10
Recipes - Smoothies	14
Contact Us	15
Notes	15
Guarantee	16

Chicken and Mushroom Soup

Preparation time: 20 minutes

Cooking time: 30 minutes

Setting: Smooth

Serves: 4

Ingredients:

- 2 tbsp olive oil
- 1 medium onion, finely chopped
- 1 garlic clove, chopped
- 240g mushrooms, thinly sliced
- 100g cooked chicken, shredded
- 10g parsley, chopped
- 1 medium potato, finely cubed
- 1litre chicken stock, fresh or made from cube
- 100ml whipping cream

Method:

- 1 In a large frying pan add the olive oil and fry the onion until soft, but not browned.
 - 2 Add the garlic and mushrooms and continue to cook until the mushrooms have softened.
 - 3 Transfer to the Soup Maker with the shredded chicken, parsley, potato and stock. Select the smooth setting and simply wait for 21 minutes until the soup maker has finished.
 - 4 Season with salt and milled pepper and serve with a drizzle of cream.
- NOTE: Using fresh chicken stock will improve the flavour of the soup.
 - To make fresh chicken stock. Simply place the left over carcass in a medium pan, cover with water, add a vegetable stock cube, 5 peppercorns and a bay leaf. Bring to the boil then simmer for 1 hour. Strain through a fine sieve or muslin cloth.

Winter Lamb and Lentil Broth

Preparation time 15 minutes

Cooking time 30 minutes

Setting: Chunky

Serves 4

Ingredients:

- 2 tbsp olive oil
- 75g lamb mince
- 1 medium onion (100g), finely chopped
- 2 garlic cloves, chopped
- 1 small carrot (50g), finely chopped
- 1 potato (100g), finely chopped
- 1 medium turnip (100g), finely chopped
- 1 tbsp plain flour
- 900ml lamb stock, made from 2 cubes
- 1 tin (400g) of cooked lentils, drained
- ½ tsp chopped rosemary
- 2 bay leaves
- 1tsp Worcestershire sauce
- 1tbsp chopped parsley

Method:

- 1 In a large frying pan heat the olive oil and fry the lamb, onion, garlic, carrot, potato and turnip until the lamb has sealed and starts to brown.
- 2 Stir in the plain flour then add half of the lamb stock and remove from the heat.
- 3 Pour the lamb into the Soup Maker with the remaining stock and the last of the ingredients. Season with a little salt and milled pepper, mix ingredients together with a spoon or spatula to evenly distribute, select the chunky setting and leave until ready.

French Style Pistou

Preparation time 15 minutes

Cooking time 30 minutes

Setting: Chunky

Serves 4

Ingredients:

- 1 courgette (150g), finely diced
- 1 small potato (70g), finely diced
- 1 small onion (70g), finely diced
- 1 carrot (50g), finely diced
- 1 tin of chopped tomatoes (400g)
- 50g petit pois
- 50g spaghetti, broken into pieces
- 50g French beans, cut into 1cm pieces
- 650ml of vegetable stock, from cube
- 1 tbsp tomato puree (mix into the stock)

To Serve:

- Pesto
- Parmesan cheese

Method:

- 1 Place the soup ingredients into the Soup Maker. Season with salt and milled pepper and stir with a spoon or spatula.
- 2 Select the chunky setting and simply wait for the Soup Maker to finish.
- 3 Serve straight away with a spoonful of pesto and freshly grated parmesan cheese.

Chinese Style Chicken and Sweetcorn Soup.

Preparation time: 20 minutes

Cooking time: 30 minutes

Setting: Chunky

Serves: 4

Ingredients:

- 100g sweetcorn, from the cob or tinned, drained
- 1 red onion, finely chopped
- 100g mushrooms, thinly sliced
- 1 tsp fresh ginger, grated
- 50g cooked chicken, shredded
- 1 garlic clove, crushed
- 1.2L chicken stock
- 2tsp corn flour mixed with 1 tsp of water to form a paste
- 2tsp soy sauce
- 50-100g hot cooked noodles
- 1 red chilli, de-seeded and finely chopped
- 15g spring onions, finely chopped
- 10g chopped coriander

Method:


- 1 Place the sweetcorn kernels into the Soup Maker along with the mushrooms, red onion, ginger, shredded chicken garlic, stock and soy sauce. Pour in the cornflour paste and stir with a spoon or spatula.
- 2 Select the chunky setting and leave until ready.
- 3 Divide the hot cooked noodles between serving bowls scatter over the chilli, spring onions and coriander. Pour the soup over the noodles and serve.

Before First Use


It is important to clean your Soup Maker before first use or if it has not been used for a long period of time. See the 'Dream to clean' section for more information.

When you first use your Soup Maker you may notice some smoke/vapour emitting from the Lid, this is normal and is simply grease that is used on some parts of the appliance applied during the manufacturing process. After using a few times this will stop.


How To Use Your Soup Maker




Ensure the Soup Maker is unplugged from the mains.




Remove the Lid (2), be careful not to touch the Mixing Blade (8).
WARNING: Sharp Blades




Place all the ingredients into the Jug (3). Add the liquid last, filling up to between the max and min lines marked on the Jug.




Place the Lid back onto the Jug ensuring it is securely in place.




Plug into the mains. The icons will flash in sequence.



Press the Mode Button (9) to select the programme. The icon will illuminate.



To start the Soup Maker, press the Select On/Off Button (11). The Soup Maker will beep and begin the cooking process. The cooking time will be displayed and start to count down.



When finished, the Soup Maker will beep for 60 seconds and all four icons will flash. Unplug from the mains, remove the Lid and pour the fresh soup into a bowl.

Using Your Soup Maker

Your Soup Maker has 4 programmes.

Select your choice of programme:

Smoothly does it... (12)

The smooth soup programme is perfect for delicious soup recipes requiring a smooth consistency, such as roast tomato & basil soup. The programme ensures the ingredients are blended to the right consistency and gently cooked at the right temperature. The programme lasts for 21 minutes and then your soup is ready to serve & enjoy!

Get chunky! (13)

The chunky soup programme is perfect for rustic soup recipes requiring a chunkier consistency, such as winter lamb & lentil broth. The programme allows the ingredients to be heated for longer to ensure the chunky ingredients are fully cooked. The programme lasts for 28 minutes, and then your soup is ready to serve & enjoy! For chunky soup there is no blending process, just heating. It is therefore recommended that you cut any vegetables into small dice sized pieces. If your soup is a little too chunky after cooking, select the blend function to gain your desired consistency.

Juice it! (14)

The juice setting on the Soup Maker is ideal for making smoothies or milkshakes from fresh ingredients. The programme lasts for 2 minutes before your drink is ready to serve. The juice setting does not heat the ingredients, so its perfect for ice cold drinks in hot weather.


Note: Do not place ice cubes in the Soup Maker.

A perfect blend! (15)

The blend setting allows you to further blend the soup to your desired consistency, if required. This function works without additional heating of the soup.

To access this function after cooking, you will need to unplug your Soup Maker before replugging into the mains. This resets the Soup Maker, allowing you to select the Blend Setting with the Mode Button. When highlighted, press and hold the Select On/Off Button (11) to blend the contents of the Jug.

LED Screen (10)



Your Soup Maker utilises 3 different processes to create fresh soups and drinks; heating, resting and blending. Each of these processes are highlighted during the programme with a small animation on the LED Screen.

Heating

The heating animation will appear in motion when the Soup Maker is heating the contents of the Jug.

Butternut Squash, Chilli and Coconut Soup

Preparation time 15 minutes

Cooking time 30 minutes

Setting: Chunky

Serves 4

Ingredients:

- 2 tbs olive oil
- 500g butternut squash, de-seeded, peeled and cut into small cubes
- 1 tsp ground cumin
- 1 large red chilli, finely chopped, (remove the seeds for a milder taste)
- 3 garlic cloves, sliced
- 1 medium onion, chopped
- 1 tsp fresh ginger
- 500ml vegetable stock, made from cube
- 200ml coconut milk
- Juice of 1 lime
- 10g fresh coriander

Method:

- 1 In a large frying pan heat the olive oil and fry the butternut squash for 2-3 minutes, stirring every so often.
- 2 Add the ground cumin, chilli, garlic and onion; continue to cook for a further 5 minutes until the ingredients start to soften.
- 3 Transfer to the Soup Maker and add the remaining ingredients, mix ingredients together with a spoon or spatula to evenly distribute.
- 4 Place the lid on the jug and select the chunky setting.
- 5 Once ready season to taste and serve. If you would like a smooth soup simply press the blend button until you have your desired consistency.

Really Quick and Easy Pea, Ham and Mint Soup

Preparation time 5 minutes

Cooking time 21 minutes

Setting: Smooth

Serves 4

Ingredients:

- 600g frozen peas
- 20g fresh mint, leaves only
- 225g quality cooked ham, chopped/shredded
- 100g potato, diced
- 800ml hot stock, from cube (ham)
- Salt and ground black pepper
- 2tbsp olive oil
- 75ml (3 heaped tbs) crème fraiche

Method:

- 1 Place the peas, mint, ham and hot stock into the soup maker and select the smooth setting.
- 2 Season with a little salt and milled pepper add the olive oil and crème fraiche and using the blend button blend the soup again for 20 seconds and serve.

Basic Vegetable Soup

Preparation time: 5 minutes

Cooking time: 21 minutes

Setting: Smooth

Serves: 4

Ingredients:

- 700g assorted vegetables, diced. (Bagged mixed vegetables from the supermarket is ideal)
- Water (filled to max mark)
- 2tsp instant chicken or vegetable stock
- Salt and ground black pepper

Method:

- 1 For a quick smooth soup fill the Soup Maker past the 1.3L mark with a selection of diced vegetables (using ready prepared chopped vegetables is ideal.)
- 2 Add the vegetable or chicken stock powder and fill to the max mark with water.
- 3 Select the smooth setting. Once the soup is ready, season to taste and serve.

Roast Tomato and Basil Soup

Preparation time: 10 minutes

Cooking time: 40 minutes

Setting: Smooth

Serves: 4

Ingredients:

- 8 very ripe tomatoes cut in half
- 2 red onions cut into wedges
- 4 garlic cloves
- 1tbsp olive oil
- 1 tbsp balsamic vinegar
- Salt and ground black pepper
- 750ml chicken stock, made from stock cubes
- 2 tsp tomato puree
- 1 tsp brown sugar
- 10g fresh basil

Method:

Pre-heat the oven to 200°C / Gas Mark 6.

- 1 Place the tomatoes skin side up into a roasting tin with the red onion and garlic. Drizzle over the olive oil, balsamic vinegar and season with salt and milled pepper. Roast for 20 minutes until softened and slightly charred.
- 2 Carefully place the roasted vegetables into the Soup Maker pour in the chicken stock, add the tomato puree, brown sugar, fresh basil.
- 3 Select the smooth setting. Once the soup is ready, season to taste and serve.

Blending

The blending animation will be displayed when the Mixing Blade is in use. When switching from heating to blending the Soup Maker will make a single audible beep.

Resting

During the programmes the Soup Maker will occasionally 'rest,' at which point no animation will be shown. But the timer on the LED Screen will continue to count down. This is normal.

Note: During the resting period do not lift the Lid (2) as this will void the programme. Once the process is completed the soup maker will beep for 60 seconds and the screen will display the 'completed' icon.

Completed

When completed, your Soup Maker will show the same animation as resting, but the timer will be at '0' and all four icons on the panel will flash.

The Benefits Of Homemade Soup

Homemade soup tastes great, costs so little and is a healthy, sustaining meal.

Scratch it!

Scratch cooking is the best way to prepare wholesome food that the whole family loves. It gives you complete control over the food you eat, because it involves cooking from the most basic ingredients and helps you to avoid all the preservatives, flavourings and other additives found in processed foods.

Batch it!

Batch cooking is great because it allows you to cook up a batch of wholesome food and pack it away in meal-sized portions that can be refrigerated or frozen, locking away all the taste and nutrients ready to enjoy later in the week.

Don't waste it!

In the UK we waste up to 8,3 million tonnes of food every year, most of which could have been eaten. Whether its forgotten chicken from Sunday lunch or a lonely tomato tucked away at the back of the fridge, you can always rustle-up a fantastic homemade soup recipe using the leftover food that would normally go to waste.

Soup Nutrition

Homemade soup couldn't be better for you, and depending on the recipe can provide a full range of nutrients including vitamins, minerals, carbohydrate and fibre. Best of all, homemade soup is simply delicious!

What Makes Your Soup Maker So Special?

Works in a flash!

Making fresh homemade soup in the comfort of your own kitchen couldn't be quicker when using your Soup Maker. All you have to do is prepare your selected ingredients, transfer them into your Soup Maker and select your required style of soup – smooth or chunky. The smooth soup programme blends and gently cooks the soup in 21 minutes. The chunky soup programme takes just 28 minutes before it's ready to enjoy!

Keeping it simple

At Morphy Richards, we believe life shouldn't be complicated. That's why we've worked hard to make your Soup Maker as easy to use as possible. It really couldn't be simpler. All you have to do is select your desired programme with one press of a button and then walk away. In as little as 21 minutes you've got perfectly delicious homemade soup, cooked your way.

Space Saver

We know that space is a valuable commodity in your kitchen. Your Soup Maker is a compact size with a simple design so it fits easily on any work-top space.

Any Questions?

If you have any questions about the use of your Soup Maker, check the list below where we have answered some of the more common frequently asked questions (FAQ's). If you require further help, please contact our Helpline: 0344 871 0944.

Does the heating function work when I remove the lid?

No. Removing the lid cuts the power to the unit for maximum safety. The heating function only activates when you have placed on the lid and selected either smooth or chunky soup programmes.

Can I remove the lid mid-cycle?

Yes, but the power will be immediately cut to the blending blade for your safety. Power will also be cut to the control panel, so you will need to start the programme again from the beginning, after replacing the lid.

Can I use my Soup Maker to make anything other than soup?

No. The 4 available programmes are set to make perfect soup and drinks from scratch. Follow the recipes and adapt them to your own taste.

Can I use uncooked meat in soup recipes made in my Soup Maker?

You should first cook meat separately before transferring into your Soup Maker with additional ingredients from your recipe, as the Soup Maker is only designed to gently heat the soup.

What is the capacity of my Soup Maker?

The capacity of your Soup Maker is 1.6L. This is marked on the inside and outside of the base. Ensure you do not fill your Soup Maker above this line, otherwise the overflow detector will cut the power to the blending blade and the LED screen (10) will display 'E1'. If this happens, simply remove some of your ingredients so the 1.6L fill mark is not exceeded and wipe clean the Over Fill Sensor (6) on the Lid (2). Ensure your ingredients (including liquid) are above the 1.3L line, failure to do this will impair the blending function.

Can I change the times on the smooth and chunky soup settings?

No. The times for these settings are preset.

Can I reheat soup I have already made, or reheat tinned/carton soup?

No. The programmes are set to make perfect soup from scratch. The soup could burn to the base of the element causing damage to the product.

What if my Soup Maker stops working?

Your Soup Maker is fitted with a safety thermostat, which cuts the power and stops the product from working to prevent overheating if it is used continuously on 3 or more cycles. If this happens, remove any food from the jug and allow the Soup Maker to cool for 30 minutes and you can continue making your soup.

If the blend function is used continuously for more than 20 seconds a safety cut out will cut the power to prevent overheating. When this happens wait for 10 seconds before reusing the blend function.

Can I make cold soups like Gazpacho in my Soup Maker?

Yes, but you will first need to cook the soup using either the chunky or smooth soup setting. Then simply allow to cool or refrigerate before enjoying.

What if food burns on the base of my Soup Maker?


Due to the starch and sugars present in some foods, a slight burning may occur if they are placed in direct contact with the inside base of the jug. To prevent this, add half a cup of water or stock to the Soup Maker before placing in any solid ingredients. Then top up with the remaining liquid specified in your recipe.

A Dream To Clean

The Soup Maker is not dishwasher safe, but it is simple and easy to clean. After use, simply wash the Motor Housing (7) and Mixing Blade (8) with warm water, and wipe with a sponge. **DO NOT** immerse in water. The inside of the Soup Maker Jug (3) can also be cleaned with warm soapy water and a sponge. If food is burned on, allow to soak and then wipe away with a sponge. Wipe the outside of the appliance with a soft, dry cloth.

Certain food types can burn if in contact with the base heating element. If this happens, fill the Soup Maker with hot soapy water and allow to soak for 15 minutes. Any burnt on food can then easily be removed with a coarse sponge cleaning pad. Do not use a metal scouring pad as this will scratch the base.

After cleaning, dry all parts thoroughly.



WARNING: DO NOT immerse the lid or jug in water, as this contains electrical components that can be damaged by water. Do not allow water to get onto the electrical connections. Dry thoroughly before use.

Recipes



We have developed 11 recipes for you to use in your new Soup Maker, from rich hearty soups to refreshing smoothies.

The Chunky Setting (13) only cooks the ingredients, it will not chop them. If after cooking, the soup is a little too chunky for your taste, you can use the Blend Setting (15) to help break down some of the chunks.

To access this function, you will need to unplug your Soup Maker before plugging into the mains. This resets the Soup Maker, allowing you to select the Blend Setting with the Mode Button (9). When highlighted, press and hold the Select On/Off Button (11) to blend the contents of the Jug.

The recipes have been developed to fit within the minimum and maximum working levels of the Soup Maker (1.3-1.6L).